



Toro Golf Controller Board Identification Guide



Thank you for choosing Jerry Pate Company for your irrigation parts and service needs. In the following pages, you will find a thorough Parts Identification Guide for Toro golf controllers and satellites. This list includes the Toro Osmac G3 and E-Series, Lynx Smart Satellite, Lynx Smart Hub 2-Wire System, Toro VP and VPe, Toro LTC, Toro RDR Osmac, Toro Network LTC 4.0, and Toro LTC+.

Upon identification of your parts, you may visit our online parts ordering system, [JP Online](#), select your parts, and order them at the click of a button.

Should you have any questions, please feel free to contact one of our team members in our Customer Care Department by phone 800-700-7004, or email customercare@jerrypate.com.

Thank you for your business!

-Jerry Pate Company



Toro Osmac G3 and E-Series



Osmac – G3 and E-Series



Part# **R118-2986**


Description: Osmac G3 timing mechanism



Part# **R102-0187**

Description: Narrow band decoder

Osmac – G3 and E-Series





Part #: **R102-0318**

Description: Output Distribution PCB



Part #: **R102-0320**

Description: Pump & Common PCB




Part #: **R102-8390**

Description: Surge PCB


Osmac – G3 and E-Series



Part #: R102-8242
Description: Output Module LEAD FREE



Part #: R102-8392
Description: 24 VAC. Bar PCB



Part #: R102-8393
Description: Earth Ground PCB

Lynx Smart Satellite





Lynx Smart Satellite



Part #: **R118-6363**

Description: LSS Timing Mechanism

Lynx Smart Satellite - Front



Part #: R118-3339
Description: LSS Radio Int PCB Assy




Part #: R118-3442
Description: Raveon Radio



Part #: R118-3045
Description: LSS Dist Board PCB Assy



Lynx Smart Satellite - Front



Part #: **R118-6369**

Description: LSS Pump Common Relay PCB Assy

Use for stations 1 thru 16 only



Part #: **R118-6370**

Description: LSS Relay Output Board Assy


Use for stations 17 thru 64 only

Lynx Smart Satellite - Back



Part #: R118-3128

Description: LSS Dist Expan Board PCB Assy



Part #: R118-6034

Description: LSS Pump Common Terminal Board with Lvl 4 Surge

Lynx Smart Hub 2-Wire System




Lynx Smart Hub





Part #: **R118-4728**

Description: LSH TM

Lynx Smart Hub - Front



Part #: R118-0582
Description: 2Wire Mother Board
Works with R118-0584 Daughter Board



Part #: R118-0584
Description: 2Wire Mother Board
Works with R118-0582 Daughter Board

Lynx Smart Hub - Back



Part #: R118-3101SK
Description: Raveon Radio

Toro VP &; VPe



Toro VP and VPe



Part #: R102-3497-4.0

Description: Timing Mechanism – Version 4.0




Part #: R102-9738

Description: Timing Mechanism, Version VPE

Toro VP and VPe



Part #: **R102-8577**
Description: Pump Module, Lead Free




Part #: **R102-8576**
Description: Power Distribution Board, Lead Free



Part #: **R102-8242**
Description: Output Module, Lead Free

Toro VP and LTC




Part #: **R102-8570**

Description: Universal Modem, Lead Free




Part #: **R102-8277**

Description: Radio Adaptor Board, Lead Free



Part #: **R102-8568**

Description: Standard Modem, Lead Free




Part #: **R363-4638**

Description: Maxon Radio Transiever

Toro RDR Osmac




Toro RDR Osmac



Part #: **R102-2012**

Description: Narrow Band RDR Decoder



Part #: **RNLN3491A**

Description: Triac Board

Toro Network LTC 4.0



Toro LTC+



Part #: **R102-8078**

Description: Distribution Board, Lead Free





Part #: **R102-8082**

Description: Pump Common Module, Lead Free



Part #: **R102-0238**

Description: Timing Mechanism



Part #: **R102-0681**

Description: 8-Output Module